



Important information regarding **#viruses** for holders of **#Freedom** and **#FreedomPure** machines for surface disinfection and cleaning:

2x two white  
spoons of salt  
4x activations  
« High »

Let the jug  
cool down  
between each  
activation  
(Wait for a beep)

Clean the  
base of your  
machine with  
white vinegar  
every week

You reached  
the virucide  
norm  
EN14476\*

- Fill the jug to 600ml (volume of the spray bottle).
- Pour two full white spoons of salt and mix the solution with the blue spoon.
- Activate the "High" mode by pressing the button twice (duration of hydrolysis is 5 minutes) and repeat this activation 4 times, always in "High" mode.  
**Important:** allow the machine to cool down between each activation (remove the jug from the base and wait for 3 min until you hear a beep) before activating the solution again.
- Once filled up, keep the spray bottle away from light and heat.
- Reactivate the solution, without adding salt, every 3 days to maintain a high disinfection efficiency (1 Activation)

aquama® has obtained standard EN14476 which measures the effectiveness of products for encapsulated and non-encapsulated **viruses such as coronaviruses**, standard EN / CH / BS14476 Virucide (\*) at 1,000 ppm under clean conditions. Currently aquama® cannot test its solution on the COVID-19 stem cell as it is forbidden for laboratories to isolate it for testing."

(\*Poliovirus, Murine Norovirus, Adenovirus & in dirty conditions, use at 2000 ppm or 5 activations). [#ecology](#) [# disinfection](#) [#cleaning](#) [#bio](#) [#aquama](#) [#swiss](#)

- Please respect the manual instructions.

