

Virucidal procedure for the disinfection of surfaces using the Freedom® Pure and Freedom® machines (EN14476* Virucide standard):

For 600 ml of mixture (spray bottle capacity):

	FREEDOM® PURE	FREEDOM®
<p>Number of activations: 4 cycles (duration of each cycle: 5 min)</p>	<p>> 2 white spoonsful of salt</p> 	<p>> 1 white spoonful of salt</p> 
<p>Caution: 15 min of downtime between each cycle.</p>	<p>> Press 2 consecutive times to activate "High" mode</p>	<p>> Press 1 time (single mode - equivalent to "High")</p>

If the hydrolysis system does not engage, add 400 ml of water to obtain 1 litre to dilute the solution (do not add salt).

- Stir the solution well with the large spoon to dissolve the salt.
- Between each activation, remove the container from the base for at least 15 minutes, and disconnect the plug from its base to enable the machine to cool faster.
- Reactivate the solution every 3 days by activating it **one time (do not add salt)** - Press 2 times (High) on a Freedom® Pure, 1 time (High) on a Freedom®.
- Keep the spray bottle away from light and heat.
- Regularly descale the inside of the container with vinegar.
- When not being used, never leave the container on its base, whether empty or full.



Remember that the machines (Freedom® Pure + Freedom®) are not designed to make virucidal solution at a regular rate. Please only prepare the solution in case of a risky situation.

Above all, observe the rules set by your local authority : Stay at home, wash your hands regularly and thoroughly, practice social distancing, avoid shaking hands, cough or sneeze into a tissue or inside your elbow, and always call before visiting the doctor's office or emergency room.

We have received FOPH (the Swiss Federal Office of Public Health) approval that our solution is virucide and bactericide (EN1276, EN1650, EN13697, EN13727 and EN14476 standards, all tested in both clean and contaminated conditions). It is registered under the number CHZN5805.

(*Poliovirus, Murine Norovirus, Adenovirus / In contaminated conditions of 2,000 ppm or 5 activations).

We remain available to serve you. Feel free to contact us at pacific@aquama.com and take care of yourself!